


# INSTALLATION OF 4 MULTISWITCHES

Up to 64 receivers can be used with 4 SWM-16s.

Do not use splitters on legacy multiswitches. Run two lines to each DVR, one to each receiver. Use B-Band Converters.



Difficulty (1 star is easiest) ☆☆☆  
DOCUMENT DATE: July, 2014