


INSTALLING GENIEGO 2

Installation options for customers with and without SWM technology

OPTION 1

Ethernet cable from router or switch (must be on same network and IP address range as DIRECTV equipment)





To power supply, plugged into wall outlet

OPTION 2 (SWM required)

To Dish or SWM

Use open port on existing splitter





To power supply, plugged into wall outlet

OPTION 3 (SWM Required)

Supplied splitter

To Dish or SWM



To power supply, plugged into wall outlet



Disconnect cable from receiver or DVR and connect to supplied splitter. Use supplied cable to connect back to receiver or DVR.



Difficulty (1 star is easiest) ☆☆
DOCUMENT DATE: March, 2014