INSTALLING A
SWM-32 MULTISWITCH

Polarity locker & Amplifier
are required for proper operation

Lines from Slimline-5 dish
Any line can connect to
any port on the 4SATPL

**Make sure lines to multiswitch
come from the correct ports:**

20V ⇨ 18V
14V ⇨ 13V
2022 ⇨ 18V/22
1422 ⇨ 13V/22

Maximum 8 receivers
(8 tuners)
per output port

DIRECTV
4x8 Channel SWM
(SWM-32)

Power supply not shown.
Use PI-29Z or Sonora PS24
into Coaxial power connector