


INSTALLATION: AMPLIFIER AND POLARITY LOCKER

Lines from Dish



Lines 1-4 may come from any of the four primary inputs on the dish. Line 5 must come from output 5 and Line 6 must come from output 6.

TO MULTISWITCHES